

RAC

2000W Pressure Washer

RACHP2000



Waste electrical products should not be disposed of with household waste.
Please recycle where facilities exist.



Check with your local authority or retailer for recycling advice.

SAFETY AND WARNING INFORMATION

General Safety Rules

WARNING: Read the instructions fully before using the product for the first time. Failure to follow the instructions may result in fire, electric shock and or serious injury.

We recommend the user wears safety equipment during use.

We recommend the product be used with a RCD (Residual Current Device).

Please Retain These Instructions For Future Use And Referral

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
When operating the unit in high pressure mode the lance may cause kickback. Therefore please ensure that you hold the spray gun firmly. When using the unit we recommend that other people are at least 10m away from the working area.
- High-pressure jets can be dangerous if misused. The jet **MUST NOT** be directed at yourself, other people, animals, live electrical equipment or the pressure washer itself. The trigger gun safety lock prevents the trigger from accidentally being engaged. This safety feature does not lock trigger in the 'on' position.
- Do not use the pressure washer if the supply cord or other important parts are damaged (e.g. high pressure lance or hoses). Never carry your pressure washer by the cord.
- Do not disconnect the high-pressure hose whilst the system is under pressure. This system is capable of producing 1600PSI. To avoid rupture and injury, do not operate this pump with components rated less than 1600PSI working pressure (including but not limited to spray guns, hose and hose connections.)
- Do not use acids or flammable liquids in the machine.
- When using a pressure washer always ensure that your water connection is protected by a backflow preventer (as per water byelaws). This will avoid possible contamination of your water supply. Use cold water feed only.
- Protect the unit against freezing, avoid storing the machine where it may be susceptible to frost.
- Prior to starting the pressure washer in cold weather, be sure ice has not formed in any part of the equipment.
- The unit must continuously run with water. Dry running will cause serious damage to the seals.

IMPORTANT: The pressure washer is equipped with an auto stop device. When the trigger is released it will open the power circuit to the motor and cause the pressure washer motor to stop. The motor will resume when the trigger is pulled. The pressure washer is also equipped with a main power ON/OFF switch located on the unit. It should always be moved to OFF position when the pressure washer is not being used. This product is a class II product-double insulated. No means of grounding (to earth) is provided on this product nor should it be added. Only a qualified person should carry out servicing. If an extension lead is to be used with this product, please ensure:

Use only extension cords that are intended for outdoor use.

Completely unwind the cable from the drum to allow for full current rating of the extension cable.

To reduce the risk of electrocution, keep all connections dry and off the ground.

Do not touch plug with wet hands

Hose: Water supply hose must be at least ½" in diameter with a minimum recommended length of 7.5 meters and be fitted with a suitable coupling that matches the male quick fit connector.

- Use only original spare parts from the manufacturer or approved by the manufacturer.
- **WARNING:** High pressure hoses, fittings and couplings are important for the safety of the appliance. Use only hoses, fittings and couplings recommended by the manufacturer.

COMPONENTS



Component List

- | | |
|-----------------------------|-----------------------------------|
| 1. On/Off switch | 12. Hose reel handle |
| 2. Water supply inlet | 13. Main handle assembly |
| 3. High pressure outlet | 14. High pressure connection hose |
| 4. Cleaning needle | 15. Hose reel connection point |
| 5. Quick fit male connector | 16. Rotary brush |
| 6. Patio cleaner extension | 17. Fixed brush |
| 7. Lance holder | 18. Adjustable lance |
| 8. Trigger gun | 19. Turbo lance |
| 9. Hose reel | 20. Patio cleaner |
| 10. Detergent container | 21. Water inlet filter |
| 11. Mains cord hook | |

Technical specification






Rated voltage:	240V ac	Max output flow rate:	6.6 L/min
Rated power:	2000 Watt	Cable length:	5 M
Rated frequency:	~ 50 Hz	High pressure hose length:	5 M
Protection class:	II	Noise value:	95 Lwa
Degree of protection:	IPX5	Noise value:	73 Lpa
Permissible pressure:	150 Bar		
Rated pressure:	110 Bar		
Max Inlet pressure:	7 Bar		
Supply water temperature:	0 - 40° C		

ASSEMBLY

Before carrying out any assembly or disassembly of the unit please ensure that the unit is not connected to the electrical supply.

Assembling your Machine


1. Fit the mains cord hook (11) to the side of the main body, as shown in Fig 1.
2. Fit the lance holder (7) to the main body, as shown in Fig 2.
3. Locate the main handle assembly (13) onto the main body, as shown in Fig 3. Secure as shown using the screws supplied.
4. Fix the hose reel handle (12) to the hose reel (9), as shown in Fig 4.
5. Ensure the walter inlet filter (21) is fitted. The screw the quick male connector (5) onto the water supply inlet (2), as shown in Fig 5.



Note: if the filter is not fitted it will invalidate the guarantee


ASSEMBLY - cont

6. Push the high pressure connection hose (14) into the high pressure outlet (3) and then screw on the outer sleeve to fix in position (Fig 6). Similarly, fit the opposite end to the hose reel connection point (15).
7. Connect the high pressure hose (on the hose reel) (9) to the trigger gun (8), as shown in Fig 7.
Note: Use a 17mm spanner (not supplied) to secure the hose.
8. Fit the adjustable lance (18) to the trigger gun (8) by pushing the lance into the gun, locate the lugs, then turn clockwise to lock in position (Fig 8).
9. Connect your garden hose to the unit via the fitted quick fit male connector (5).



Patio Cleaner Assembly

1. Fit the patio cleaner extension (6) onto the patio cleaner (20).
Push and turn to lock the bayonet fitting.
2. Attach the trigger gun (8).
Note: All these fittings are bayonet fittings which push in then twist to lock.



Note: Always check that you will not damage the surface area prior to use on an inconspicuous test area first.

OPERATING INSTRUCTIONS

Note:

Before connecting to the mains power supply please ensure that the ON / OFF switch is in the OFF position (fig 10) and the water supply is connected and is turned on. Running the pressure washer without any water supplied to it will damage the pump




Fig 09

Instructions for use

- With the unit fully assembled, ensure that the unit is switched OFF and is connected to the mains supply and the water supply. Pull the trigger a few times to expel any air trapped in the system.
- Ensuring that the trigger is released, switch ON the pressure washer. The unit is now ready to operate by pulling the trigger.

Note:


The motor only runs when the trigger is operated. When the pressure washer is not in use, actuate the gun lock for safety reasons (Fig 11). Switch the unit OFF when not in use for extended periods of time. Never operate the pressure washer without the water supply connected and turned on.



Fig 10

Helpful Hints

Before starting cleaning remove any objects which could create a hazard. Ensure that all doors and windows are closed (where appropriate). The adjustable lance allows you to use a variety of spray patterns from a fan to a pencil jet (fig 12). When using the pressure washer to clean decking, patios, vehicles, etc., always start by using the fan spray and begin spraying from a minimum 30cm away to avoid damaging the surface of the material to be cleaned.



The spray is adjustable from a pencil jet spray to fan spray by tuning the nozzle shown (Fig 12).

WARNING: Do not adjust the nozzle while the trigger is squeezed.

The pressure of the spray on the surface you are cleaning increases as you move the nozzle closer to the surface. We recommend that for most cleaning applications a 45° spray angle should be used to avoid damaging the surface being cleaned. Spraying directly head-on tends to cause dirt particles to embed in the surface. The turbo lance is a fixed nozzle, which effectively increases the area of the high pressure water jet and decreases the time required to clean larger areas like patios. The turbo nozzle provides a circular water pattern as it sprays high-pressure water. The spray pattern on this nozzle is not adjustable. The circular spray action does heavy cleaning in less time.

Pre-operation

ADJUSTING FAN PATTERN

The angle of spray coming out of the lance may be adjusted on some lances by rotating the nozzle. This will vary the spray pattern from approximately a 0° narrow high impact stream to a 60° wide fan spray. (See Fig 13)




Figure 13 – Adjusting nozzle for fan pattern (not applicable on some nozzle)

A narrow stream has high impact force on cleaning surface and results in maximum deep cleaning in a concentrated area. However, this narrow high impact spray must be used cautiously, as it may damage some surfaces.




Figure 14 – Narrow high impact stream

A wide fan pattern will distribute the impact of the water over a larger area, resulting in excellent cleaning action with a reduced risk of surface damage. Large surface areas can be cleaned more quickly using a wide fan pattern.





Figure 15 – Wide fan pattern

NOZZLE CLEANING INSTRUCTIONS

A clogged or partially clogged nozzle can cause a significant reduction of water coming out of the nozzle and cause the unit to pulsate while spraying. To clean out the nozzle:

- Turn off and unplug the unit.
- Turn off the water supply and relieve any pressure within the unit by squeezing the trigger 2-3 times
- Separate the lance from the gun.
- Rotate the nozzle to the narrow stream setting. This opens up the fan blades.
- Using the cleaning needle (16) or an unfolded paper clip, insert the needle into the nozzle hole and move it back and forth until the debris is dislodged (Fig 16)



- Remove additional debris by back-flushing water through the nozzle. To do this, place the end of a garden hose (with water running) to the end of the nozzle for 30-60 seconds.

HOW TO AVOID DAMAGING SURFACES

Damage to cleaning surfaces occurs because the impact force of the water exceeds the durability of the surface. Never use a narrow high impact stream or a turbo/ rotary nozzle on a surface that is susceptible to damage. Avoid spraying windows with a narrow high impact stream or turbo nozzle as this may cause breakage. The surest way to avoid damaging surfaces is to follow these steps:


1. Before triggering the gun, adjust the nozzle to a wide fan pattern.
2. Place the nozzle approximately 4-5 feet from and angled at 45 degrees to the cleaning surface and begin spraying.
3. Vary the fan pattern spray angle and the distance to the cleaning surface until optimum cleaning efficiency is achieved without damaging the surface.

TURBO NOZZLE

A turbo nozzle, sometimes referred to as a rotary nozzle, is a very effective tool that can significantly reduce cleaning time. The turbo nozzle combines the power of a narrow high impact stream and the efficiency of a 25 degree fan pattern. This swirls the narrow high impact stream into a cone shape that cleans a larger area.

CAUTION: Since a turbo nozzle uses a narrow high impact stream, only use it in applications where the cleaning surface cannot be damaged by a narrow high impact spray. Note: The turbo nozzle is NOT adjustable and cannot be used to apply detergent.

Rotary brush



Before using the rotary brush:

- a. Ensure that the brush is clean and free from debris.
- b. Ensure that the surface to be cleaned is sound and is suitable for being cleaned by the vigorous rotary action of the brush. If you are unsure, check on a small inconspicuous area first.
- c. Important - Any grit on the surface to be cleaned or in the brush can cause damage to the surface as it is being cleaned.

Low/High Pressure Adjustable Lance



High Pressure Setting:

Please make sure the trigger is released and no water is coming out, then turn the rear part of the spray nozzle anti-clockwise (Fig 17) to set to high pressure.

Low pressure Setting:


Please make sure the trigger is released and no water is coming out, then turn the rear part of the spray nozzle clockwise (Fig 18) to set to low pressure.

CAUTION: Selection of high or low pressure must be carried out with the trigger off.



WATER INLET FILTER

The water inlet filter must be inspected regularly, so as to avoid blockage and restriction in the water supply to the pump (Fig 19).



USING DETERGENT

Add detergent to the container and replace the cap. Please note the minimum level required, Set the adjustable lance at low pressure position (page 6 Fig 13).

Depress trigger to spray detergent.

DETERGENTS

The use of detergents can dramatically reduce cleaning time and assist in the removal of difficult stains.

Some detergents have been customized for pressure washer use on specific cleaning tasks. These detergents are approximately as thick as water.

The use of thicker detergents, such as washing-up liquid, will clog the chemical injection system and prevent the application of the detergent.

The cleaning power of detergents comes from applying them to a surface and giving the chemicals time to break down the dirt and grime. Detergents work best when applied at low pressure.

Follow this with a high pressure rinse for best cleaning results.

On vertical surfaces, apply the detergent starting at the bottom and work your way upward.

This will prevent the detergent from sliding down and causing streaks.

High pressure rinsing should also progress from the bottom upwards.

On particularly tough stains it may be necessary to use a brush in combination with detergents and high pressure rinsing.

Operation

The following cleaning procedure will help you organize your cleaning task and ensure that you achieve the most beneficial results in the shortest amount of time.

Remember to use the spraying/ cleaning techniques previously listed.

1. Surface preparation

It is important to prepare the surface that is to be cleaned. This is done by clearing the area of furniture and making sure that all windows and doors are closed tight. In addition, you should make sure that all plants and trees adjacent to the cleaning area are protected by a drop cloth. This will ensure that your plants won't be sprayed by the detergents.

2. Initial High Pressure Rinse

The next step is to spray the cleaning surface with water to clear off any dirt or grime that may have collected on the surface. This will allow your detergent to attack the deep down dirt that has worked its way into the cleaning surface. Before triggering the gun, adjust the nozzle to a wide fan pattern and slowly adjust to the desired spray pattern.

This will help you avoid applying too much concentrated spray to the surface which could cause damage.

TIPS FOR EXTENDING THE LIFE OF YOUR PRESSURE WASHER

1. Never operate the unit without water.
2. This pressure washer is not designed to pump hot water. Never connect it to the hot water supply – this will significantly reduce the life of the pump.
3. Only use detergents specifically designed for pressure washers. Other types of detergent may cause internal damage to the unit, as might chemicals such as bleach, washing-up liquid, etc.
4. Never operate the unit for more than one (1) minute without spraying water. Otherwise, the resulting heat buildup will damage the pump.
5. Winter Storage:
For storage during the winter months we recommend the use of a solution of 50/50 mix of antifreeze and water. This will keep the pump from freezing and getting damaged and will protect the internal components.

Method: You will need a length of garden hose and a funnel. Attach the garden hose to the inlet and pour the antifreeze into the unit via the funnel.

Switch the unit on for a few seconds to allow the solution to flow through the system. Disconnect your pressure washer from the mains power, then pack away in your storage area.

WARNING: Before reusing completely flush the unit out with plain water. Anti-freeze can damage paintwork so you must ensure there is no antifreeze left in the system before using it again.

Troubleshooting chart

Symptom	Possible cause (s)	Corrective Action(s)
Pressure washer does not start	<ol style="list-style-type: none"> 1. Unit is pressurized 2. Poor plug connection or faulty outlet socket 3. Extension cord too long or undersized 4. Main voltage supply too low 	<ol style="list-style-type: none"> 1. Squeeze trigger on gun 2. Check plug, socket 3. Remove extension cord 4. Check that main supply voltage is adequate
Pump does not reach necessary pressure	<ol style="list-style-type: none"> 1. Water inlet filter is clogged 2. Pump sucking air from hose connections 	<ol style="list-style-type: none"> 1. Clean water inlet filter 2. Check that connections and locking ring are properly tightened
Fluctuating pressure	<ol style="list-style-type: none"> 1. Pump sucking in air 2. Clogged nozzle 	<ol style="list-style-type: none"> 1. Check that hoses and connections are tight 2. Clear blockage with cleaning needle (see page 5)
Motor stops suddenly	<ol style="list-style-type: none"> 1. Extension cord too long or undersized 	<ol style="list-style-type: none"> 1. Remove extension cord
No detergent suction	<ol style="list-style-type: none"> 1. Using high pressure setting 2. Not enough detergent 	<ol style="list-style-type: none"> 1. Use low pressure setting 2. Add detergent up to min level

Plug fitting

Note: If a moulded plug is fitted and has to be removed take great care in disposing of the plug and severed cable, it must be destroyed to prevent engaging into a socket. If the supply cord is damaged it must be replaced by a service agent or similarly qualified person in order to avoid hazard. Your pressure washer is supplied with a fitted plug, however if you should need to fit a new plug follow the instruction below. If in doubt consult a qualified electrician.


IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

Blue - Neutral Brown - Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red. No connection is to be made to the earth terminal of the plug. If a 13 AMP (BS 1363/A) plug is used, a 13 AMP fuse must be fitted, or if any other type of plug is used a 13 AMP fuse must be fitted, either in the plug, or adaptor or on the distribution board.





Read Instruction manual



This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE).

This means that this product must be handled pursuant to European Directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment.

For further information, please contact your local or regional authorities.

Electronic products not intended in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances.

*If faults cannot be remedied, contact the **Helpline** on **020 8391 6767***

Helpline@hilka.co.uk

GUARANTEE

This product is guaranteed for domestic use for a period of 12 months against faulty manufacture or materials.

This guarantee does not affect the statutory rights of the consumer. In the event of any problem occurring please contact our Helpline at the number above for advice. This product is not guaranteed for **HIRE** purposes.

Produced under license for Halco Products Ltd
Booths Hall, Booths Park, Chelford Road,
Knutsford, Cheshire WA16 8QZ England